FD25

User Manual

I. Charging

A. Make sure device is turned off
B. Plug into USB charger
C. Charging is complete when red charging light turns off

II. Recording

A. With device unplugged or plugged in, turn device on
B. Recording begins automatically
C. To stop recording, turn device off

III. Playing Back Files

A. Make sure device is turned off
B. Plug into USB charger
C. Open up your computer file viewer and open the removable drive
D. Access files to listen, copy, or delete

Note:

- If the drive becomes full, or the battery is too low, the device will save current recording, and power down.
- When device is turned on, recording will begin automatically anytime the noise level is above 40db (roughly the sound of a library, or birds chirping)